



Retractable Banner Stands

INSTRUCTIONS




Carefully remove the banner stand and segmented pole from the padded carry bag.




RS Models:
Turn stabilizing foot pad to a 90° angle.



LD Models:
Proceed to Next Step




Assemble the segmented pole into one long extended pole, and insert into the hole on the back of the banner stand.




While holding onto the pole with one hand, carefully expand the graphic by pulling it in an upwards direction, out of the base, until fully extended. Fasten the top bar to the pole, by either attaching it to the grey clip (LD1 / LD2) or by attaching the hook (RS1 / RS7) to the top of the pole.


Optional Accessories:




Molded Plastic
Shipping Case




50w / 110v Light




Optional:
To insert light onto the top of the pole, align the hook through the center groove of the light base and press until secure.



LD Series Stand & Bag



RS Series Stand & Bag



Segmented Pole



Horizontal Top Bar